

GEWA G5 / G3 Update Guide

This is an instruction on how to update the software of your GEWA G5 or G3 Module.

To update the Module you need a USB stick and the software update package for your GEWA G5 / G3. You can find available software updates for your model at: <https://gewadrums.com/en/service>

.....

How to update the Module?

1. Download the Software Package from www.gewadrums.com
2. Unzip the download and you'll find the update file

Installation of the Firmware

Please install the firmware first:

1. Copy the 5916ED-Gx-FW.bin file into the root directory of an **empty** USB stick
2. Plug the stick into the USB port of your Module
3. Start the Module while pressing the buttons F1 + F3 (keep them pressed during the boot process)
4. Wait until it the display shows "Firmware V X.XX"
5. Press enter to start the installation process
6. Switch Off your Module

**** If the installation process does not start automatically, please try using a different USB stick.***

.....

Important Information

We highly recommend doing a factory reset after the installation process. If you don't want to do a factory reset, please reload your trigger settings to take advantage of the trigger improvements.

Do you have trouble installing your Software update? Our technical support is happy to help you! Please write an email to edrumsupport@gewamusic.com