

GEWA G9 Update Guide

This is an instruction on how to update the software of your GEWA G9 Drum Workstation.

To update the GEWA G9 you need an USB stick and the software update package for your GEWA G9. You can find available software updates for your model at:

www.gewadigitaldrums.com/en/downloads

You can see the different software versions in the General Settings mode in the General information tab.

How to update the G9?

1. Download the software package from our website. This download is packed as a .zip file, so you need to unpack the data to your PC. Save the .swu file in the directory to the root directory of you USB stick. Please make sure, that there are no other files available on your USB stick.
2. Plug in the USB to your G9 and switch it on.
3. After switching it on there should a pop-up appear: "Updating Firmware – Do NOT switch off the device"
4. When the update is finished the display shows: "Firmware update complete..."
5. Please remove your USB-stick and reboot the GEWA G9 now.
6. The new firmware version number should now appear in the general settings section in the information tab.

Having trouble installing your software update? Our technical support is happy to help you! Please write an email to edrumsupport@gewamusic.com